

## READ ME FIRST – SETUP INSTRUCTIONS

Congratulations on your purchase of the UltraAV™ HDMI 2-1 Audio/Video Switch. This HDMI switch is designed to provide exceptional performance and value. It allows access to 2 HDMI devices using a single HDMI display. For use with a DVI device, use an optional HDMI to DVI adapter or HDMI to DVI cable.

### Features:

- Supported Resolutions: 480i, 480p, 720p, 720i, and 1080i, 1080p (1920 x 1200 computer resolution)
- Supports HDCP compliant devices
- Infrared extender included
- No external power needed

### Includes:

- HDMI 2-1 switch
- Infrared (IR) extender
- IR remote control (with battery)
- Setup instructions

**About the IR Extender:** In order to operate the HDMI switch with the remote control the switch must be in the line-of-sight of the remote control. The switch has a built-in IR sensor that communicates with the remote control. If the HDMI switch will be placed out-of-sight then the IR extender, with its built-in IR sensor, should be used. The remote control will communicate with the switch through the IR extender.

### How to Connect the HDMI Switch:

**Step 1:** If locating the HDMI switch in an out-of-sight location, plug the IR extender into the open port on the side of the HDMI switch. Place the end of the IR extender in a location that is visible to the remote control. The end of the IR extender is fitted with adhesive tape. Remove the backing to use the tape.

**Step 2:** Connect your sources HDMI cables into the inputs labeled "1" and "2" on the HDMI switch.

**Step 3:** Connect your HDMI cable from your display (or projector) into the "I/O" port on the HDMI switch.

### Inserting the Battery Into the Remote Control:

The remote control is powered by an included 3V "coin" battery (Panasonic CR2025). To insert the battery, remove the battery holder located on the lower rear of the remote control. While pushing the slotted tab inwards (unlocking the compartment) pull the battery holder out. The battery holder allows the battery to be inserted only in the correct position. Slide the battery holder back into the remote control.

### How to Operate the HDMI Switch:

1. Use the push button on the HDMI switch to manually toggle between sources.
2. Alternatively, use the remote control to remotely toggle between sources.

### Troubleshooting:

-If the HDMI switch fails to operate using **BOTH** the manual push button and the remote control,

1. Ensure the HDMI sources and the display (or projector) are powered on.
2. Check both ends of each HDMI cable to ensure that they are fully inserted into each device.

-If the HDMI switch works with the manual push button but fails to operate using the remote control,

1. Ensure the remote control or the IR Extender are in line-of-sight to the remote control
2. Unplug all the cables, including the IR extender if used, from the HDMI switch. Reconnect all of the cables in the order described above in "**How to Connect the HDMI Switch**".
3. Replace the remote control battery. See "**Inserting the Battery Into the Remote Control**" above.

**Assistance:** If you have questions regarding the Accell HDMI switch, please check out our Web site at: [www.accellcables.com](http://www.accellcables.com). Technical Support can be reached at 510-438-9288 (M-F 9am-5pm PST).

The information above is believed to be accurate, however Accell assumes no responsibility for any inaccuracies and liability for direct, indirect, special, incidental, or consequential damages as a result. Due to ongoing improvements, Accell reserves the right to make changes to hardware, packaging and any accompanying documentation without prior written notice. UltraAV is a trademark of Accell Corporation. For warranty information please check out our Web site or contact Technical Support at the phone number above.