



## MHL to HDMI Adapter

### **Instructions for use**

1. With the power to the TV off, connect an HDMI cable from the HDMI port on the MHL adapter to your HDMI TV or other HDMI device.

Note: Supplying power to the connected MHL source device will allow the source device to remain charged while being used. Use the charger supplied or approved by the manufacturer of your mobile device.

2. If power to the MHL device is desired, connect the USB Micro-B cable from your mobile devices supplied travel charger to the CHARGE port on the side of the adapter. See note below.

3. Plug your mobile device's supplied travel charger into a power source.

4. With the MHL enabled device turned off, connect the MHL adapter's USB Micro-B connector to the MHL enabled source device.

5. Turn on the TV and MHL source device.

6. Configure the TV to the HDMI input being used. Refer to the TV's instructions for more information.

7. If needed, configure your MHL enabled device to output audio and/or video through the MHL connector. Refer to the source device's instruction manual for more information on enabling the MHL output.

Note: The use of a power adapter is dependent upon the source device's ability to supply power from its USB Micro-B port.